



*marzocchi*

**BOMBERZ1**

TUNING GUIDE

## SAG SETTING


To achieve the best performance from your Marzocchi suspension, adjust the air pressure to attain your proper sag setting. Sag is the amount your suspension compresses under your weight and riding gear. Sag range should be set to 15-20% of total fork travel.

Make sure to set sag with the compression lever in the OPEN mode, see page 5.

### *Suggested Sag Measurements*

Travel	15% sag (Firm)	20% sag (Plush)
130 mm (5.1in)	19.5 mm (0.7in)	26 mm (1.0 in)
140 mm (5.5 in)	21 mm (0.8 in)	28 mm (1.1 in)
150 mm (5.9 in)	22 mm (.9 in)	30 mm (1.2 in)
160 mm (6.3 in)	24 mm (1.0 in)	32 mm (1.3 in)
170 mm (6.7 in)	26 mm (1.0 in)	34 mm (1.3 in)
180 mm (7.1 in)	27 mm (1.1 in)	36 mm (1.4 in)

Your fork has a 4 digit ID code on the back of the lower leg. Use this number at [www.Marzocchi.com](http://www.Marzocchi.com) to find out more information about your fork, including fork travel.





The recommended settings in this tuning guide are designed to be a **starting point**, in order to get you out on your first ride in as few steps as possible. Consult your bike manufacturer's instructions for setup recommendations.

As you ride and get used to your new fork, adjust your settings as needed. Detailed information and videos can be found in the online owner's manual.

*Suggested Starting Points for Setting Sag*

Rider Weight (lbs)	Rider Weight (kgs)	BOMBER Z1 Pressure (psi)
120-130	54-59	55
130-140	59-64	59
140-150	64-68	63
150-160	68-73	67
160-170	73-77	72
170-180	77-82	76
180-190	82-86	80
190-200	86-91	85
200-210	91-95	89
210-220	95-100	93
220-230	100-104	97
230-240	104-109	102
240-250	109-113	106



Do not exceed maximum air pressure:  
**BOMBER Z1** maximum air pressure is **120 psi**.


## REBOUND ADJUSTMENT

The rebound adjustment is dependent on the air pressure setting. For example, higher air pressures require slower rebound settings. Use your air pressure to find your rebound setting.


**Turn your rebound knob to the closed position, clockwise until it stops. Then turn it counter-clockwise to the number of clicks shown in the table below.**

### REBOUND

**Rebound** controls the rate of speed at which the fork extends after compressing.



Rider Weight (lbs)	Rider Weight (kgs)	BOMBER Z1
120-130	54-59	13
130-140	59-64	12
140-150	64-68	11
150-160	68-73	10
160-170	73-77	9
170-180	77-82	8
180-190	82-86	7
190-200	86-91	6
200-210	91-95	5
210-220	95-100	4
220-230	100-104	3
230-240	104-109	2
240-250	109-113	1



**GRIP COMPRESSION ADJUST**

The **2-Position Sweep Adjust** lever is useful to make on-the-fly adjustments to control fork performance. Use the positions between OPEN and FIRM modes to fine-tune your compression damping.




## ***INSTALLING THE FRONT WHEEL- 15QR***

1. Install the front wheel into the fork dropouts. Slide the axle through the non-drive side dropout and hub.
2. Open the axle lever fully and rotate the lever so it is engaged in the axle housing notch.



3. With the lever engaged in the notch, turn the axle clockwise 5-6 complete turns into the axle nut.
4. Adjust the axle tension by tightening the axle clockwise so that you start to feel resistance when closing the QR lever 90 degrees away from full closure. Note that once the QR is out of the axle housing notch, the QR lever can be rotated to a proper position of 1-20 mm in front of the fork.
5. Close the lever. The lever must have enough tension to leave an imprint on your hand.



### **KABOLT INSTALLATION**

1. Install the front wheel into the fork dropouts. Slide the Kabolt axle through the non-drive side dropout and hub.
2. Use a 6 mm hex wrench to torque the Kabolt axle (clockwise) to 17 Nm (150 in-lb).



**⚠ WARNING:** Use hand pressure only. Never use any tool to tighten the 15QR levers onto the lower legs. Over-tightening the levers can damage the axle or fork dropouts, leading to a sudden failure with one or more of these components, resulting in **SERIOUS INJURY OR DEATH**.

**⚠ WARNING:** Failure to secure the axle properly can cause the wheel to become detached from the bicycle, resulting in **SERIOUS INJURY OR DEATH**.


## ***MOUNTING DISC BRAKES***

The BOMBER Z1 uses 180 mm post mounts that allow you to bolt your caliper directly to the fork and utilize a 180 mm rotor.

If your current 180 mm brake setup came with bolts and a caliper spacer, you may need to source shorter bolts as you will not need a caliper spacer when using a 180 mm rotor.

If using a 203 mm rotor, you will need to source the appropriate caliper spacer and bolts. Contact the brake manufacturer for further information.

**⚠ WARNING:** Follow your brake manufacturer's installation instructions for proper installation and adjustment of the brake system. Failure to properly install and adjust your brakes can lead to a loss of control of the bicycle which can result in SEVERE INJURY OR DEATH.



← 2x M6 x 1,0-6H  
(full thread 12mm)

Disc brake caliper mount bolts must have 10-12mm of thread engagement.

Torque bolts to manufacturer's specification. Bolt torque must not exceed 90 in-lb.

## ***ADDITIONAL TUNING OPTIONS***

### ***CLIP-ON VOLUME SPACERS***

Changing volume spacers in the BOMBER Z1 fork is an easy internal adjustment that allows you to change the amount of mid stroke and bottom out resistance.

If you have set your sag correctly and are using full travel (bottoming out) too easily, then you could install one or more spacers to increase bottom out resistance.

If you have set your sag correctly and are not using full travel, then you could remove the spacer to decrease bottom out resistance.


Installation procedure and tuning options are available online at:  
**[www.Marzocchi.com](http://www.Marzocchi.com)**

*BOMBER Z1 Volume Spacer  
Configurations*

<b>Travel</b>	<b>Volume Spacers Factory Installed</b>	<b>*Max Volume Spacers</b>
180 mm	1	5
170 mm	1	6
160 mm	2	7
150 mm	3	7
140 mm	4	8
130 mm	5	8



## TYPICAL AIR SPRING CURVES



**SEE ADDITIONAL INFORMATION AND VIDEOS:**

**[MARZOCCHI.COM](http://MARZOCCHI.COM)**



***NOTES***

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



***marzocchi***

©MARZOCCHI. 2017 // 1.800.369.7469  
915 Disc Drive, Scotts Valley, CA 95066 USA  
605-00-173 REV A

**MARZOCCHI.COM**